













echnical data	Symbol Ra	tings:	II	III	IV		V	Unit
Rated operational voltage	Ue	1000	850	800	650		400	V dc
Rated operational current	le	16	20	25	30		45	A dc
								2
Required fine wire cross-section	on (minimal)*:	2,5	4,0	4,0	6,0		10,0	mm²
*IEC60947-1, table 9								
Number of DC poles							2	
Utilization category DC						DC	-21B	
Pollution degree							2	
IP rating terminals							IP20	
Tightening torque terminal scr	rews M4 (min ma	x.)			1,5	_	1,7	Nm
Method of mounting								
IP rating of the shaft in case of	single hole and fo	ur hole panel mounting					IP65	
Tightening torque panel moun	nting nut (min ma	ax.)			2,0	-	2,5	Nm
Panel thickness between					1	_	4	mm
Positions		12 (0	FF) and 3 o'd	lock (ON)				
Actuator	ctuator Standard A knob with long screw to fix in shaft							
Method of operation		Indep	endent man	ual operat	ion			
Actuator operation force (max	(.)						1,4	Nm
Tightening torque M3 screw in	n the actuator (min	- max.)			0,2	-	0,4	Nm
Rated impulse withstand volta	ige	Uimp					8	kV
Insulation voltage		Ui					850	٧
Rated thermal current uninter	rupted duty	lu					45	Α
Rated short-time withstand cu	irrent (1s)	lcw					700	Α
Rated short-circuit making cap	pacity	lcm					1,4	kA
Rated conditional short-circuit	current	Isc					5	kA
Minimum required dimension	s of enclosures L x \	W x D* {space envelope}		124	x 47	Х	64	mm
* see the drawing for the heigh							2	
Weight		,				ca.	137	g
Allowed ambient temperature	(min max.)	T _{ambier}	nt		-40	-	70	°C
Allowed storage temperature	· · · · · · · · · · · · · · · · · · ·	T _{storage}			-40	-	85	°C
Relative humidity (max.), with	out condensation	at 20°C RH					90	%

Recommend Manufacturer	Type number	Wire size (AWG)	Wire size (mm²)	Color
JST	FVD2-YS4A	AWG 16 – AWG 14	1,0 – 2,5 mm²	Blue
TE connectivity	C-165012	AWG 16 – AWG 14	1,0 – 2,5 mm²	Blue
Vogt	3635c	AWG 16 – AWG 14	1,5 – 2,5 mm²	Blue
TE connectivity	C-165015	AWG 12 - AWG 10	3,0 - 6,0 mm ²	Yellow
Vogt	3652c / 3653c	AWG 12 - AWG 10	3,0 - 6,0 mm²	Yellow
Santon (JST)	52A1256.35	AWG 8 - AWG 10	10,5mm²-16mm² *1	*2





						2			
Terminals Scheme									
Layer	Front Side		Symbol	Rear Side		Positions			
No.	Left	Right	Symbol	Left	Right	1	2	3	4
7									
6									
5									
4									
3									
2	-1	1		-1		I			0
1		+1 -			+1	I			0

(I = Contact is closed, 0 = Contact is open)

Mounting instructions

In the application all ratings according to the datasheet have to be respected. After mounting, the wiring must be checked and the switch must operate smoothly. When building the switch in an enclosure, the space envelope must be respected according to the applicable standards.

Maintenance

The X type switches are designed for a very long life but it is advised to do some simple yearly maintenance.

- Check the installation for signs of overload or overheating. The terminals may not exceed the limit of 85oC $\,$ under full load.
- By operating the switch a few times (5x) the contacts will clean themselves and the switch will have a longer life.

${\tt Connection}$

The terminals, can take copper wires up to 6 mm2.
The recommended Spade Tongue Terminals may have a maximum width of 9 mm (see table for recommendations)

- *1 $\,$ 16mm² only with fine stranded wire (or two times 6mm²)
- *2 Optional: A yellow finger safe sleeve for the Spade Tongue Terminal (Santon 52A1256.35) can be ordered under item number 52A1564.00